
Alternator warning light
yellow
Engine running safety unit
red
green/red
black
3 A
red
red
+ Battery -
Fuse holder
pos 1: 3 A
pos 2: 15 A
pos 3: 15 A
pos 4: 3 A
black
green
red
black
Pressure regulator
blue/red
white
yellow
green
black
green
cover
line bundle
TIM
ground
valve
pump
LPG-tank
Electronic control unit ECU)
L-probe
Main relay
Fuel Switch
Resistor box
Diagnostic
Ground Engine
Battery+ (clamp 30)
red Battery+ (clamp 30)
blue/red engine running safety relay
black ground engine
red/white power supply 5V
yellow
white signal LPG pressure
yellow ground LPG pressure
grey/red
pink
yellow/white ground L-sonde
purple/white signal L-sonde
grey/white
grey/black
brown/black
brown/white
orange/black
orange/white
white signal TIM
yellow ground TIM
black ground LPG
blue/white Pump control
green/black LPG valves
white signal Fuel Switch
orange/black rxd (receive)
orange txd (transmit)
yellow/black signal ground general
orange petrol injector 6 IN
orange/green petrol injector 6 OUT
yellow/green petrol injector 5 OUT
yellow petrol injector 5 IN
grey/green petrol injector 4 OUT
grey petrol injector 4 IN
blue petrol injector 3 IN
blue/green petrol injector 3 OUT
brown/green petrol injector 2 OUT
brown petrol injector 2 IN
white/green petrol injector 1 OUT
white petrol injector 1 IN
black ground LPG
black
black
black
red
red
green/white LPG injector 3
grey/white LPG injector 1
red/yellow LPG injector 2
blue/green LPG injector 6
green/yellow LPG injector 4
blue/black LPG injector 5
LPi injector
Cyl 5 green
Cyl 4 white
Cyl 6 grey
Cyl 2 blue
Cyl 1 red
Cyl 3 yellow
LPi-injectors
Cyl 6
Cyl 5
Cyl 4
Cyl 3
Cyl 2
Cyl 1
Petrol-injectors