











	Battery+ Accu+ Batterie+ +Batterie
	Ground engine Massa motorblok Masse motorblock Masse bloc moteur
	Fuses Zekeringenhouder Sicherungshalter Fusibles
	Main relay Hoofdrelijs Hauptrelais Relais principal
	Resistor box Weerstandenkastje Zu ersetzende widerstände Résistance de remplacement
	Coupling block Koppelblok Drückregleinheit Bloc de couplage
	LPE-7 LPE-7 LPE-7 LPE-7
	LPI Diagnostic tool (LDT) LPI Diagnostic tool (LDT) LPI Diagnostic tool (LDT) LPI Diagnostic tool (LDT)
	Switch Schakelaar Schalter Sélecteur
	Probe λ-sonde λ-sonde λ-sonde
	Engine running safety Motorloop signaal Motorstartrelais Sécurité moteur en marche
	LPG injectors LPG injectoren LPG injektoren LPG Injecteurs
	Petrol injector interrupt Onderbreken benzine injectoren Benzin injektoren unterbrechen Injecteurs d'essence

	EN	NL	DE	F
BN	brown	bruin	braun	brun
BU	blue	blauw	blau	bleu
BK	black	zwart	schwarz	noir
GN	green	groen	grün	vert
GY	grey	grijs	grau	gris
OR	orange	oranje	orange	orange
PK	pink	roze	rosa	rose
PU	purple	paars	lila	violet
RD	red	rood	rot	rouge
WH	white	wit	weiß	blanc
YE	yellow	geel	gelb	jaune